

Devices compatible with the WisePad

Operating System	Operating System level	Phones
iOS (Apple)	Version 8 or higher	<ul style="list-style-type: none"> • iPhone 4S and up • iPad 3 and up (all models)
Android	Version 4.4.2 or higher (Versions 4.4.4 and 5.0 are not supported due to issues with the Android Bluetooth software in these versions)	<ul style="list-style-type: none"> • Samsung • Google Nexus • Sony • HTC • Etc. <p>Note: There are other Android devices that are supported that are not listed above as we have not managed to test all devices on the market and there are other models in different markets.</p>
Blackberry (10)	Z & Q Platform OS 10.3.1 and higher	<ul style="list-style-type: none"> • Q10 • Z10 • Passport • Classic • Leap • P'9983 & P'9982 (Porsche Design) • Z30 • Q5
Windows	Windows 7 and up on desktop and tablets Windows 10 and up on mobile (soon to be discontinued by Microsoft)	All PC's, Tablets and phone.
Not Supported	All	<ul style="list-style-type: none"> • Huawei Phone <p>Not supported as phones are unable to pair with Mswipe device</p>